Merk	Type		Color	Year
Turntables				
Aiwa	AP-2200	turntable	black	1977 - 1979
Aiwa	PX-30	turntable	silver	
Akai	AP-001C	turntable	silver	
Akai	AP-100	turntable	gray	1980
Akai	AP-100	turntable	antracite	1980
Akai	AP-100C	turntable	antracite	1978
Akai	AP103C	turntable	Antraciet/zilver	1978
Akai	AP206C	turntable	antracite	1978
Akai	AP-D30	turntable	silver	1980 - 1982
Akai	AP-D30	turntable	black	1980 - 1982
Akai	AP-D40	turntable	antracite	1980
Akai	AP-D40	turntable	silver	1980
Akai	AP-X1	turntable	silver	1985 - 1988
Aristona	AR-8540	turntable	black/silver	1974 - 1976
Aristona	8549	turntable	black/silver	1975
Aristona	1312	turntable	woodcase/silver	1976
Aristona	1312	turntable	woodcase/silver	1976
Aristona	1312	turntable	woodcase/silver	
Aristona	5877	turntable	antracite	1978
Audio Reflex/Marantz	MR-116	turntable	woodcase/silver	70's
Audio Sonic	System 2000	turntable	black/silver	1975 - 1979
Bang&Olufsen	Beogram 1000	turntable	woodcase/black	1967 - 1972
Bang&Olufsen	Beogram 1203	turntable	white/silver	1974 - 1976
Bang&Olufsen	RX-2	turntable	silver/antracite	1985 - 1991
CEC	BD-2000	turntable	woodcase/black	1974 - 1976
Denon	DP-30L	turntable	silver	1981
Dual	CS 503-1	turntable	black	1987 - 1989
Dual	CS 505-2	turntable	black	1984 - 1989
Dual	CS 505-3	turntable	black	1987 - 1990
Dual	CS 505-4	turntable	black	2003 - ?
Dual	CS 505	turntable	woodcase/silver	1980
Dual	CS 506	turntable	antracite	1979 - 1980
Dual	CS 506	turntable	silver/black	1979 - 1980
Dual	CS 515	turntable	antracite	
Dual	CS 607	turntable	black	1981 - 1983
Dual	CS 610 Q	turntable	silver	1983 - 1986
Dual	CS 617 Q	turntable	black	1981 - 1982
Dual	CS 617 Q	turntable	silver	1981 - 1982
Dual	CS 704	turntable	woodcase/black	1976 - 1979
Dual	CS 721	turntable	woodcase./black	1979 - 1982
Dual	CS 721	turntable	woodcase/black	1979 - 1982
Dual	1015	turntable	woodcase/black	1963 - 1968
Dual	1019	turntable	woodcase/black	1966 - 1969
Dual	1210	turntable	woodcase/black	1976 - 1979
Dual	1210	turntable	woodcase/black	1969 - 1971

Dual	1210	turntable	woodcase/black	1969 - 1971
Dual	1214	turntable	woodcase/silver	70's
Dual	1214	turntable	woodcase/silver	70's
Dual	1218	turntable	white/black	1972 - 1975
Dual	1218	turntable	white/black	1972 - 1975
Dual	1225	turntable	woodcase/black	1973 - 1975
Dual	1225	turntable	woodcase/black	1973 - 1975
Dual	1226	turntable	woodcase	1974 - 1978
Dual	1254	turntable	black	
Dux (Zweedse Philips)	202	turntable	woodcase/silver	1969 - 1973
ERA	5055	turntable	black/silver	1975
Erres	RS-3535	turntable	woodcase-black	1975
Erres	RS-3535	turntable	woodcase/silver	1975
Erres	RS-8540	turntable	black/silver	1975
Erres	1222	turntable	woodcase/black	1976
Erres	5877	turntable	antracite	1978
Garrard	AT-6	turntable	woodcase/silver	1962
Garrard	SP25	draaitafel	woodcase/antracite	1967
Garrard	SP-25 MKII	turntable	woodcase/silver	1967 - 1970
Garrard	86 SB	turntable	woodcase	1974 - 1976
Hitachi	HT-354	turntable	silver	1978 - 1980
JVC	AL-FQ555	turntable	black	1989 - 1992
JVC	L-F66	turntable	silver	1980 - 1982
Kenwood	KP-2022A	turntable	woodcase/black	1973
Lenco	B-55	turntable	woodcase	1972 - 1974
Lenco	L-65	turntable	woodcase/black	1975
Lenco	L-70	turntable	woodcase/black	1959 - 1965
Lenco	L-75	turntable	woodcase/silver	1972 - 1979
Lenco	L-76	turntable	woodcase/black	1976
Lenco	L-76	turntable	woodcase/black	1976
Lenco	L-76	turntable	woodcase/black	1976
Lenco	L-76/S	turntable	woodcase/black	1974 - 1979
Lenco	L-90	turntable	black	1975
Lenco	L-90	turntable	silver/black	1975
Lenco	L-90	turntable	woodcase/black	1975
Lenco	L-236	turntable	black	1977 - 1979
Lenco	L-247	turntable	black	1979
Lenco	L-331	turntable	silver/black	1977 - 1983
Lenco	L-833 DD	turntable	black	1977
Lenco	L-833 DD	turntable	black	1977
Lenco	L-833 DD	turntable	black	1977
Luxman	PD-272	turntable	woodcase/silver	1977 - 1982
Luxman	PD-284	turntable	black/silver	1982 - 1985
Luxman	PD-288	turntable	woodcase/silver	1982 - 1985
Marantz	Model 6150	turntable	woodcase/black	1977 - 1979
Marantz	TT 320	turntable	champagn	1982 - 1984
Marantz	TT 1200	turntable	champagn	1981 - 1983
Marantz	Model 6025	turntable	champagn	1978

Marlux	MX-56	turntable	woodcase/black	
Marlux	MX-56	turntable	woodcase/black	
Marlux	MX-66	turntable	woodcase/black	1976
Marlux	MX-66	turntable	woodcase/black	1976
Marlux	MX-66	turntable	woodcase/black	1976
Marlux	MX-146	turntable	silver/black	1975 - 1980
Marlux	MX-860	turntable	grey	1980?
Micro Seiki	DD-1	turntable	woodcase/black	1974 - 1976
Mitsubishi	DP-780	turntable	silver alu	1981 - 1983
National Panasonic	SL-18	turntable	black	1976 - 1978
National Panasonic	SL-18	turntable	dark grey	1976 - 1978
National Panasonic	SL-41	turntable	woodcase/black	1969 - 1973
Onkyo	Integra CP 1057F	turntable	black	1989 - 1990
Onkyo	CP-1260F	turntable	woodcase	1980 - 1982
Philips	GA 108	turntable	black/silver	1973 - 1976
Philips	GA 146	turntable	woodcase/silver	1968 - 1971
Philips	GA 230	turntable	woodcase/silver	1968 - 1971
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1973
Philips	202	turntable	woodcase/silver	1969 - 1972
Philips	202	turntable	woodcase/silver	1969 - 1972
Philips	202	turntable	woodcase/silver	1969 - 1972
Philips	209	turntable	silver	1974
Philips	209	turntable	silver	1974
Philips	209	turntable	silver	1974
Philips	209	turntable	silver	1974
Philips	212	turntable	silver/black	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	308	turntable	woodcase/silver	1972 - 1975
Philips	308	turntable	woodcase/silver	1972- 1975
Philips	312	turntable	black/silver	1976 -1977
Philips	312	turntable	woodcase/silver	1976 - 1977
Philips	312	turntable	woodcase/silver	1976 - 1977
Philips	312	turntable	woodcase/silver	1976 - 1977
Philips	312	turntable	woodcase/silver	1976 - 1977
Philips	312	turntable	woodcase/silver	1976 - 1977
Philips	408	turntable	silver	1973 - 1976

Philips	408	turntable	woodcase/silver	1973 - 1976
Philips	427	turntable	woodcase/silver	1980
Philips	437	turntable	silver/black	1980
Philips	437	turntable	silver/black	1980
Philips	437	turntable	silver/black	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	222	turntable	silver	1980
Philips	867	turntable	antracite	1978
Philips	877	turntable	antracite	1978
Philips	F-7211	turntable	silver aluminium	1983
Philips	F-7215	turntable	silver	1981
Philips	F-7222	turntable	silver	1983 - 1984
Philips	F-7226	turntable	silver	1983 - 1984
Philips	F-7511	turntable	silver	1982
Philips	FP-142	turntable	silver	
Philips	FP-142	turntable	antracite	
Philips	FP-563	turntable	black	1995?
Philips	FP-563	turntable	black	1995?
Philips	AF-673	turntable	antracite	1978 - 1980
Philips	AF-684	turntable	antracite	1979 - 1980
Philips	AF-729	turntable	black/silver	1980 - 1982
Philips	FP-780	turntable	black	
Philips	AF-829 Mk-II	turntable	silver alu	1980 - 1982
Philips	AF-829-Mk-II	turntable	silver alu	1980 - 1982
Pioneer	PL-10	turntable	woodcase/black	
Pioneer	PL-12D	turntable	woodcase/black	
Pioneer	PL-51A	turntable	woodcase/black	1974
Pioneer	PL-120D	turntable	woodcase/black	1972 - 1976
Pioneer	PL-510	turntable	woodcase/silver	1976 - 1978
Pioneer	PL-510	turntable	woodcase/silver	1976 - 1978
Pioneer	PL-514	turntable	silver/gold	1977 - 1979
Pioneer	PL-514X	turntable	black	1980 - 1982
Project	1-Xpression III	turntable	black gloss	2012 - ?
Project	1.2 Comfort	turntable	black matt	2002 - ?
Project	P1.2E	turntable	black matt	2015 - ?
Project	RPM 1.3 Genie	turntable	black	2012 - ?
Project	6-Perspex	turntable	transparent/black	2008 - 2016
Project	P 6.1	turntable	black/glass	1995
Realistic	Lab 65	turntable	grey	1979
Realistic	Lab 400	turntable	woodcase	1978
Rega	P-3	turntable	black matt	2007 - 2012
Reloop	RP-1000 mk3	DJ-turntable	chrome	2014 - 2017
Rotel	RP-900	turntable	woodcase/black	1992 - 1997

Sansui	SR-525	turntable	black	1976 - 1978
Sansui	SR-222	turntable	black	
Scott	PS-77 XV	turntable	grey	1979 - 1981
Siera	5777	turntable	antracite	1979 - 1980
Sony	PS-212a	turntable		1978 - 1980
Sony	PS-1150	turntable	woodcase	1976
Sony	PS-3750	turntable	antracite	1976 - 1980
Sony	PS-J10	turntable	silver	
Sony	PS-FL1	turntable	silver	1982 - 1985
Sony	PS-LX22	turntable	silver	1983
Sony	PS-LX62	turntable	black	
Sony	PS-LX311	turntable	black	1980
Sony	PS-LX410	turntable	black	1984
Sony	PS-LX431	turntable	black	1986 - 1994
Technics	SL-1800 Mk-II	turntable	silver	1977 - 1981
Technics	SL-1800 Mk-II	turntable	silver	1977 - 1981
Technics	SL-1900	turntable	black	1976 - 1978
Technics	SL-2000	turntable		1976 - 1978
Technics	SL-3200	turntable	silver	1978 - 1979
Technics	SL-3310	turntable	black	1978
Technics	SL-Q02	turntable	antracite	1979 - 1981
Technics	SL-Q210	turntable	silver	1985
Technics	SL-Q210	turntable	silver	1985
Technics	SL-20	turntable	black	1975 - 1977
Technics	SL-D3	turntable	silver	1979
Technics	SL-D21	turntable	silver	
Technics	SL-B303	turntable	silver	1981 - 1983
Technics	SL-B210	turntable	silver	
Technics	SL-B210	turntable	silver	
Technics	LS-BD21	turntable	silver	
Technics	SL-230	turntable	silver	1978 - 1979
Technics	SL-230	turntable	silver	1978 - 1979
Telefunken	S-800	turntable	black	1978 - 1980
Thorens	TD-105	turntable	black	1977
Thorens	TD-110	turntable	black	1977
Thorens	TD-115	turntable	black	1977 - 1982
Thorens	TD-125 MK-II	turntable	black/silver	1972 - 1975
Thorens	TD-126 MK-III	turntable	black	1979 - 1986
Thorens	TD-126 MK-III	turntable	black	1979 - 1986
Thorens	TD-160 B MkII	only body	black/aluminium	1982 - 1985
Thorens	TD-160 B MkII	turntable	black/silver	1982 - 1985
Thorens	TD-165	turntable	woodcase/silver	1972 - 1976
Thorens	TD-165	turntable	woodcase/silver	1972 - 1976
Thorens	TD-165	turntable	woodcase/silver	1972 - 1976
Thorens	TD-166	turntable	white/silver	1975
Thorens	TD-166	turntable	woodcase/silver	1975
Yamaha	P-200	turntable	black	1982 - 1983

Tangential	**turntables**			
Bang&Olufsen	Beogram 4002	turntable	nutwood/silver	1974 - 1978
Bang&Olufsen	Beogram 4002	turntable	white/silver	1974 - 1978
Luxman	PX-101	turntable DD	silver	1982 - 1984
Luxman	PX-101	turntable DD	silver	1982 - 1984
Mitsubishi	LT-70	turntable	grey/black	1985?
Philips	FP-146	turntable	silver	1985
Pioneer	PX-X430	turntable	black	1987
Sansui	P-E750	turntable	black	1991
Siemens	RW612	turntable	silver	1984
Toshiba	SR-V10	turntable	black	1984
Technics	SL-J1	turntable BD	black	1984 - 1988
USB Turntables				
GPO	PR100	turntable	silver	2018?
Akai	ATT01U	turntable	silver	2014?
JB-Systems	1100	turntable	silver	2008?
Lenco	L3866 USB	turntable	silver	2015?
Lenco	L3866 USB	turntable	silver	2015?
Lenco	L3866 USB	turntable	silver	
Lenco	L-78 USB	turntable	silver	2020?
Xion	TTUSB05xl	turntable	silver	
Cartridges				
Philips	422 4CH	quadra/ 4 channel!	gold	1980
Philips	400MkI		black/silver	1974 - 1977
Philips	400MkII		black/silver	1977 - 1981
Philips	NOS	pickup headshells	divers	'50's /'60's
Pickering	NP/AT	met nieuwe naald		60's/'70's
Phono amplifiers				
Philips	22GA230	build-in preamp	print	
Denon	AU-320		black	1973 - 1976
Philips	22GA202	build-in pre-amp	print	
Vivanco	PA-111	phono-amp	black	
Turntable combi's				
Audio Sonic	AS 5005	turntablecombi	white/black	1978
Bang&Olufsen	Beocenter2800	turntablecombi	silver	1978
Bang&Olufsen	Beocenter3500	turntablecombi	silver	1972 - 1977

Bang&Olufsen	Beocenter4600	turntablecombi	silver	1977 - 1980
Bohland&Fuchs	Tesla NZC420	turntablecombi	woodcase/black	1980
Braun	Audio 300	turntablecombi	black/aluminium	1969
Crosley	CR8005AGR	turntablecombi	green	2013
Dual	HS-37	turntablecombi	woodcase/black	1971
Erres		turntablecombi	black	
Grundig	Studio 3010	turntablecombi	black/aluminium	1976 - 1978
Philips	onbekend	turntablecombi	woodcase/alum.	jaren '60
Philips	802	turntablecombi	woodcase/alum.	1972 1975
Philips	GF660	turntablecombi	woodcase/alum.	1973 - 1976
Philips	904	turntablecombi	antracite/aluminium	1980 - 1982
Philips	904 MkII	turntablecombi	antracite/aluminium	1983 - 1984
Philips	892	turntablecombi	woodcase/silver	1969 - 1972
Philips	832	turntablecombi	black/silver	1974
Philips	FP-9400	stereotower	black	1998?
Wega	Studio 3205	turntablecombi	woodcase/silver	1970 - 1971
Wega	Studio 3220	turntablecombi	white/silver	
Amplifiers	**Integrated**			
Akai	AM-32	amplifier 50W	black	1987 - 1990
Dual	MV60	multiphony amp	woodcase/silver	1972 - 1978
Dual	CV 40	amplifier 18W	woodcase/silver	1968 - 1972
Harman-Kardon	PM-635	amplifier 30W	antracite	1986 - 1988
LEAK	Stereo 30	amplifier 15W	black/silver	1963 - 1969
Luxman	SQ-707	amplifier 17W	silver	1969 - 1975
Luxman	LV-103U	amplifier 50W	black aluminium	1984 - 1987
Luxman	L-114A	amplifier 48W	silver	1980 - 1983
Luxman	L-205	amplifier 40W	silver	1984 - 1988
Luxman	A-312	amplifier 55W	black aluminium	1994 - 2000
NAD	319	amplifier 125W	antracite	1997
Philips	302L	amplifier 20W	silver	1982
Philips	305	MFB-amp. 52W	silver	1980
Philips	590	amplifier 15W	woodcase/silver	1971 - 1972
Philips	591	amplifier 20W	woodcase/silver	1970 - 1972
Philips	591	amplifier 20W	Woodcase/silver	1970 - 1972
Philips	591	amplifier 20W	Woodcase/silver	1970 - 1972
Philips	919	amplifier 20W	Woodcase/silver	1966 - 1868
Philips	919	amplifier 20W	Woodcase/silver	1966 - 1968
Philips	923	amplifier 12W	Woodcase/silver	1966 - 1968
Philips	FA-860	amplifier 65W	black	1986 - 1989
Sansui	AU-2900	amplifier 17W	antracite	1976 - 1977
Sony	TA-VE700	AV amplifier 50W	black	1996
Yamaha	DSP-E580	amplifier 75W	black	1994 - 1997
Pre- / Power-Amplifiers				

NAD	2140	Poweramp. 50W	Antracite	1980 - 1985
NAD	1020	Pre Amplifier	Antracite	1981 - 1986
Philips	RH-743	MFB Pre Amplifier	black	1975 - 1978
Philips	RH-743	MFB Pre Amplifier	black	1975 - 1978
Philips	RH-762	MFB Pre Amplifier	black	1976 - 1980
Servosound	Cybernetic	pre amplifier	woodcase/grey	1970
Sony	TA-E1000 ESD	Pre Amplifier	woodsides/black	1990 - 1992
Sony	TA-N55ES	Poweramp. 110W	woodsides/black	1989 - 1997
Receivers				
Akai	AA-R20	Receiver 26W	silver	1980
Akai	AA-8030	Receiver 25W	woodcase/silver	1973
Bang&Olufsen	Beomaster901	Receiver 20W	woodcase/silver	1972 - 1977
Bang&Olufsen	Beomaster1000	Receiver 15W	woodcase	1964 - 1971
Bang&Olufsen	Beomaster1200	Receiver 20W	woodcase/silver	1969 - 1973
Bang&Olufsen	Beomaster1600	Receiver 15W	woodcase/black	1971 - 1973
Bang&Olufsen	Beomaster1001	Receiver	woodcase/silver	1973 - 1976
Bang&Olufsen	Beomaster2400	Receiver	silver/glass	1978 - 1979
Bang&Olufsen	Beomaster3000	Receiver 40W	woodcase/silver	1970 - 1972
Bang&Olufsen	Beomaster3000-2	Receiver 40W	woodcase/silver	1969 - 1975
Bang&Olufsen	Beomaster3000	Receiver 40W	silver/glass	1985 - 1987
Bang&Olufsen	Beomaster3400	Receiver 4x20W	woodcase/black	1975 - 1977
Bang&Olufsen	Beomaster4000	Receiver 60W	woodcase/black	1972 - 1977
Cambridge Audio	Azur 340R	AV Receiver 80W	silver	2008 -
Dual	CR 60	receiver 30W	woodcase/black	1974 - 1976
ITT	HIFI 8030	Receiver 50W	silver	1978
Kenwood	KR3130	Receiver 14W	woodcase/silver	1970 - 1972
Kenwood	KR-V5090	receiver 50W	black	1997 - 1999
Kenwood	KR3130	receiver 60W	black	1995
Körting		receiver-cassette	woodcase/silver	
Luxman	R-404	Receiver 33W	silver	1985 - 1988
Luxman	R-5030	Receiver 35W	silver	1981 - 1984
Marantz	Model 2226B	receiver 26W	silver	1977 - 1980
Marantz	Model 1515	receiver 15W	silver	1978 - 1980
Onkyo	TX-DS494	receiver 55W	black	2001 - 2002
Onkyo	TX-SR501E	receiver 65W	silver	2003 - 2004
Onkyo	TX-SR608	receiver 100W	black	2010 -2011
Philips	603	Receiver MFB 37W	black	1980 - 1982
Philips	712	Receiver 40W	woodcase/black	1972 - 1974
Philips	741	Receiver 14W	woodcase/silver	1974
Philips	741	Receiver 14W	woodcase/silver	1974
Philips	790	Receiver 30W	woodcase/silver	1970 - 1972
Philips	FR732	Receiver 60W	black	1996
Philips	GH930	Receiver 7W	woodcase/silver	1966 - 1969
Pioneer	SX-450	Receiver 15W	woodcase/silver	1976 - 1979
Pioneer	SX-450	Receiver 15W	Zilver/woodcase	1976 - 1979

Pioneer	VSX-708	Receiver 110W	woodcase/silver	1998 - 2000
Rotel	RX-700	Receiver 35W	silver	1981
Sony	STR-AV370	receiver 50W	black	1991
Sony	STR-DE135	receiver 100W	black	1999 - 2000
Sony	STR-DE215	receiver 60W	black	1997
Sony	STR-GX70ES	Receiver 80W	woodsides/black	1990 - 1992
Technics	SA-180	Receiver 35W	silver	1987 - 1988
Technics	SA-EX100	Receiver 100W	black	1996 - 1998
Yamaha	RX-496	Receiver 75W	black	1998
Yamaha	RX-E100	receiver 40W	silver	
Yamaha	RX-E200	receiver 40W	silver	
Yamaha	RX-E400	receiver 40W	silver	
Tuners				
Akai	AT-2200	tuner	antracite	1977 - 1979
Bang&Olufsen	Beomaster5000	tuner	woodcase/silver	1968 - 1972
Dual	CT18	tuner	woodcase/silver	1975
Dual	CR40	tuner	woodcase/silver	1968 - 1972
Luxman	T-100L	tuner	black	1985 - 1988
Marantz	ST6000	tuner	black	1999 - 2004
NAD	412	tuner	antracite	1995 - 1997
NAD	4130	tuner	antracite	1985 - 1986
NAD	4225	tuner	antracite	1988 - 1990
Onkyo Integra	T 4015	tuner	silver	1983 - 1985
Optonica	ST-1515	tuner	silver	1978 - 1979
Philips	102L	tuner	silver	1982
Philips		tuner	woodcase/silver	60-s
Philips	651	tuner	black woodcase/silv	1976 - 1978
Philips	691	tuner	silver/black	1971 - 1972
Philips	691	tuner	woodcase/silver	1971 - 1972
Philips	927	tuner	woodcase/silver	1966 - 1968
Pioneer	F-449L	tuner	black	1991
Sansui	TU-505	Tuner	woodcase/black	1973 - 1975
Sony	ST-A35L	tuner	silver	1980 - 1981
Teac	T-H300	Tuner	champagne/zilver	1997 - 2003
Technics	ST-300	tuner	silver	1986 - 1987
CD Players				
Akai	CD-A405	CD player	black	
Arcam	Solo Mini	CD player	silver	2008 - 2010
Aristona	TK629	CD player	Grey	
Denon	DCD 620	CD player	black	1988 - 1990
JVC	XL-Z555	CD player	black	1988 - 1990
Kenwood	DP-710	CD player	black	1987 - 1989
Kenwood	DP-R3080	5 disc changer	black	1996 - 1997
Luxman	D-115	CD player	black	1987 - 1990
Luxman	D-373	CD player	black	1996 - 2000

NAD	5320	CD player	antracite	1990 - 1992
Onkyo	DX-1500	CD player	black	1988 - 1989
Pioneer	PD-F100	100 CD changer	black	1994 - 1995
Pioneer	CLD-160K	CD/Laserdisc	black	1996 - 1998
Pioneer	PD-4300	CD player	black	1989 - 1990
Philips	CD150	CD player	black	1985
Philips	CD160	CD player	black	1986
Philips	CD380	CD player	black	1988
Philips	CD380	CD player	black	1988
Philips	Cdi 210	CD player	black	1991 - 1993
Philips	Cdi 470	CDI player	black	1995 - 1998
Philips	CD471	CD player	silver	1988
Philips	CD600	CD player	black	1990 - 1992
Philips	CD614	CD player	black	1990 - 1992
Philips	CD634	CD player	black	1991 - 1994
Philips	CD670	CD player	black	1987
Philips	CD 753	CD player	black/silver	1997 - 1998
Philips	CDC 486	6 CD Changer	black	1989
Sony	CPD-490	CD player	black	1990 - 1992
Sony	CDP-M19	CD player	black	1989 - 1991
Sony	CDP-250	CD player	black	1988 - 1989
Sony	CDP-591	CD player	black	1991 - 1992
Sony	CDP-XE270	CD player	silver	2002 - 2007
Technics	SL-PG100	CD player	black	1991 - 1993
Technics	SL-PD688	5 CD changer	black	1998 - 1999
Yamaha	CDX890	CD player	black	1996 - 1999
Yamaha	CDX-E100	CD player	silver	1999 - 2001
Mini Disc				
Sony	CMT-SD1	minidisk player	silver	1999 - 2004
Sony	MDS-JE510	minidisk player	black	1997 - 1998
Digital Cassette Decks				
Walkmans				
Asahi (Crown)	CS-650	walkman	silver	1975
Sony	TCM-80V	walkman	silver	
Sony	D3 professional	walkman	black	
Sony	DD-Quartz	walkman	silver	
Sony	TCM-17	walkman	black	
Sony	M-205	micro-cassette	silver/black	
Philips	292	pocket-memo	black	

Cassette Decks				
Akai	CS-M02	Cassette deck FL	silver	1980 - 1981
Akai	HX-1	Cassette deck FL	antracite/silver	1983 - 1985
Akai	HX-A351W	Doubledeck FL	black	1987 - 1988
Bang&Olufsen	Beocord 5000	Cassette deck TL	woodcase/silver	1976 - 1980
Dual	C919	Cassette deck TL	woodcase/black	1974 - 1978
Grundig	C402	Cassette Deck TL	black/grey	1973 - 1974
Harman Kardon	TD202	Cassette deck FL	black	1986 - 1987
JVC	TDX 401	Cassette deck FL	black	1986 - 1987
JVC	TDX 501	Cassette deck FL	black	1986 - 1987
JVC	KD-V50	Cassette deck FL	silver	1984
JVC	KD-V300	Cassette deck FL	black	1983 - 1984
JVC	TD-W216	Double deck FL	black	1994 - 1997
JVC	TD-W301	Double deck FL	black	1989 - 1991
JVC	TD-W550	Double deck FL	black	1987 - 1989
Kenwood	KX57CW	Double deck FL	black	1988 - 1989
Luxman	K-10	Cassette deck FL	silver	1979 - 1982
Luxman	K-111	Cassette deck FL	black aluminium	1988 - 1990
Luxman	K-111	Cassette deck FL	black aluminium	1988 - 1990
Luxman	K-117	Cassette deck FL	silver	1981 - 1983
Nakamichi	BX2	Cassette deck FL	black aluminium	1982 - 1983
Nakamichi	BX2	Cassette deck FL	black aluminium	1982 - 1983
Nakamichi	BX2	Cassette deck FL	black aluminium	1982 - 1983
Nakamichi	LX-3	cassette deck FL	silver/black	1982 - 1984
Nakamichi	LX-3	cassette deck FL	silver/black	1982 - 1984
Philips	N2204	cassette deck TL	grey	1971 - 1973
Philips	N2400	cassette deck TL	woodsides/silver	1971 - 1976
Philips	N2511	Cassette deck TL	silver/black	1976 - 1978
Philips	N2511	Cassette deck TL	silver/black	1976 - 1978
Philips	N2520	Cassette deck TL	black/silver	1974 - 1976
Philips	N2521	Cassette deck TL	black/silver	1977 - 1980
Philips	N2521	Cassette deck TL	black/silver	1977 - 1980
Philips	N2543	Cassette deck FL	silver	1978
Philips	F-6133	Cassette deck FL	silver	1983 - 1984
Philips	FC-140	Cassette deck FL	silver	1985 - 1987
Philips	FC-563	Double deck FL	black	1986 - 1987
Philips	FC-566	Cassette deck FL	black	1986 - 1989
Philips	FC-783	Double deck FL	black	1988
Sansui	???	Double deck FL	black	
Sony	TC-FX150	cassette deck FL	black	1987-1988
Sony	TC-TX333	cassette deck FL	silver	1998
Sony	TC-134SD	Cassette deck TL	woodcase/black	1972 - 1974
Sony	TC-142	Cassette deck TL	black	1972 - 1974
Sony	TC-K555	Cassette deck FL	silver	1982 - 1984
Technics	RS-T230	Double deck FL	silver	1988 - 1989

Technics	RS-M22	cassette deck FL	silver	1979
Uher Report	CR240	Cassette deck TL	black	1979
Yamaha	KX-W582	Double deck FL	black	1994 - 1995
Yamaha	KX-493	cassette deck FL	black	1998 - 2001
Yamaha	TC 800GL	design deck TL	black	1975 - 1978
Speakers Passive				
Audiolab	Cresto CD	floorspeakers	black	1995?
Aristona	SA 6489	speakers 60W	woodcase-black	1979
Blaupunkt	Lab 307	speakers 40W	black/aluminium	
B&W	DM-7 Mk-I	floor speakers	woodcase/alu	1977 - 1979
Elipson	1400	speakers 80W	black	1987
KEF	Cantata SP 1056	floor speakers	woodcase, weels	1976 - 1981
Philips	zelfbouw	speakers	woodcase	
Philips	22AH432	Speakers	woodcase	
Philips	9436 DRC MkII	floor speakers	woodcase	
Pioneer		satellites	black	
Speakers Active				
B&W Solid	Active power bass	subwoofer 70W	black	1992
Nakamichi	soundspace 8,5	active subwoofers	silver	2014
Loewe	L 82 HF	active cordless	silver	2015?
KEF	Model 30B	Subwoofer 100W	black	1998
Korn&Macway Lab.	KM30	speakers	woodcase/black	1978
Philips	MFB532	Speakers	Woodcase	1973
Philips	MFB532	Speakers	Woodcase	1973
Philips	MFB541	Speakers	black	1976 - 1978
Philips	MFB544	Speakers	black	1977 - 1979
Philips	MFB544	Speakers	black	
Philips	MFB586	Speakers	black	1978 - 1982
Philips	MFB587	Speakers	black	1978 - 1982
Quad	ESL63	electrostats	brown	1983 - 1999
Set in components				
Bang&Olufsen	Beomaster2400	Receiver	silver/glass	1978
Bang&Olufsen	Beogram 1200	turntable	woodcase/silver	
Bang&Olufsen	Beovox	speakers	woodcase	
Bang&Olufsen	Beomaster5000	Receiver 55W	silver/black	1984 - 1986
Bang&Olufsen	Beocord5000	Cassette Deck	grey/aluminium	
Bang & Olufsen	Beogram CD5500	CD player	grey/aluminium	

Bang&Olufsen	Beomaster 6000	4-channel reciever!	woodcase/silver	1974 - 1978
Bang&Olufsen	Beogram 4002	tangential turnt.	woodcase/silver	1974 - 1977
Bang&Olufsen	Beocord 5000	cassettedeck TL	woodcase/silver	1975 - 1979
Bang&Olufsen	Beovox S60	4 speakers 60W	woodcase	1975 - 1976
Bang&Olufsen	U-70	headphones	silver/black	1978 - 1985
Braun Atelier	A-1	amplifier 50W	black	1978 - 1981
Braun Atelier	P-1	turntable	black	1978 - 1981
Braun Atelier	T-1	tuner	black	1978 - 1981
Braun Atelier	T-1	tuner	black	1978 - 1981
Braun Atelier	C-1	Cassette Deck	black	1978 - 1981
Braun Atelier	C-1	Cassette Deck	black	1978 - 1981
Braun Atelier	SW-1	subwoofer 150W	black	1978 - 1981
Braun Atelier		setvoet en slang	black	1978 - 1981
Braun Atelier		3 mini speakers	black	1978 - 1981
Cambridge Audio	Azur 340C	CD player	silver	2004
Cambridge Audio	Azur 340A SE	amplifier 45W	silver	2009
Cambridge Audio	Sirocco S70	floorspeaks 125W	silver/black	2009 - 2012
Dynaco	pat-4	Pre amplifier	silver	1971 - 1972
Dynaco	120	Poweramp. 60W	black	1971 - 1972
Dynaco	FM-5	Tuner/pre-amp	silver	1971 - 1972
Dynaco	FM-5	Tuner/pre-amp	silver	1971 - 1972
Dynaco	D-20XL	speakers 35W	woodcase	1977 - 1982
IXOS	1014 Gamma	interlink	grey	
Dual	VC 40	amplifier 18W	woodcase/silver	1969 - 1972
Dual	CT 16	tuner	woodcase/silver	1969 - 1971
Harman Kardon	HD720	CD player	black	1998 - 2000
Harman Kardon	HK640	amplifier 55W	black	1995 - 1998
Harman Kardon	TD420	Cassette deck FL	black	1996 - 2000
ISP	SV3000	amplifier 30W	black aluminium	DDR 1982
ISP	CTD 3000	cassette deck	black aluminium	
ISP	SP3000	turntable	black aluminium	
ISP	ST3000	tuner	black aluminium	
LEAK	Delta 30 Amplifier	amplifier 15W	woodcase/silver	1970 - 1975
LEAK	Sandwich 2020	speakers 25W	woodcase/black	1975 - 1978

Linn	Mimik	CD-player	grey	1996 - 1999
Linn	Wakonda	pre-amplifier	grey	1996 - 1999
Linn	LK 100	poweramp. 50W	grey	1996 - 1999

Luxman	T-4	Tuner	silver	1978 - 1982
Luxman	L-2	amplifier 33W	silver	1979 - 1981
Luxman	L-2	amplifier 33W	silver	1979 - 1981
Luxman	T-2	Tuner	silver	1979 - 1981
Luxman	K-12	Cassette deck	silver	1979 - 1982
Luxman	A-383	Amplifier 125W	silver/champagne	1993 - 2000
Luxman	T-341L	Tuner	silver/champagne	1992 - 1993
Luxman	D-373	CD-player	silver/champagne	1993 - 1996
Luxman	K-373	Cassette Deck FL	silver/champagne	1993 - 2000
Mitsubishi	DA-U300	amplifier 50W	silver	1984
Mitsubishi	DA-F200	tuner	silver	1984
NAD	NAD VISO FIVE	receiver/CD player	black	2009 - 2012
Philips	FR 951	Receiver 100W	antracite	1994
Philips	CD 931	CD player	antracite	1994
Philips	FC 930	Double deck	antracite	1992 - 1994
Philips	FT 930	Tuner	antracite	1994
Philips	CDC-926	CD changer	antracite	1995
Siemens	RS-555	receiver 60W 4Ohm	silver	1979 - 1983
Siemens	RW-555	turntable DD 7Kg	silver	1979 - 1983
Siemens	RC-555	cassette deck	silver	1979 - 1983
Siemens	RS-555	receiver 60W 4Ohm	silver	1979 - 1983
Siemens	RW-555	turntable DD 7Kg	silver	1979 - 1983
Siemens	RC-555	cassette deck	silver	1979 - 1983
Sony	CDP X55ES	CD player	woodsides/black	1990 - 1991
Sony	TA-F470	amplifier 80W	black	1990 - 1992
Sony	730ES	Tuner	black	1989 - 1991
Sony	TC-W320	Double deck	black	1990 - 1991
Sony	SEQ-310	Equalizer	black	1989 - 1991
Sony	MHC-3300	amplifier/tuner	antracite	1989 - 1991
Sony	TA-V10	amplifier 30W	silver	1984 - 1986
Sony	ST-V10L	tuner	silver	
Sony	TC-V10	Cassette deck	silver	
Sony		amplifier	silver	
Sony		tuner	silver	
Sony		CD-player	silver	
Sony		equalizer	silver	

Sony	TC-V3	Cassette deck	silver	1983 - 1984
Technics	SE-HD501	amplifier 24W	silver/woodsides	1998 - 2001
Technics	SL-HD501	CD Player		
Technics	ST-HD501	Tuner		
Technics	SU-5	amplifier 25W	silver	1982 - 1985
Technics	SH-E5	equalizer	silver	1982 - 1985
Technics	ST-5	tuner	silver	1982 - 1985
Technics	RS-5	Cassette Deck	silver	1982 - 1985
Technics	SL-PJ25	CD player	silver	1988 - 1990
Toshiba Aurex	ST-T10L	tuner	silver	1979 - 1981
Toshiba Aurex	SB-A10	amplifier 20W	silver	1979 - 1981
Toshiba Aurex	PC-D15	cassette deck	silver	1979 - 1981
Wega	P 3440	turntable	antracite blue	1976 - 1979
Wega	V 3841	amplifier 60W	antracite blue	1976 - 1978
Wega	T 3740-2	tuner	antracite blue	1976 - 1978
Wega	C 3941-C	cassette deck FL	antracite blue	1976 - 1978
Wega	L 3547	speakers 60W	antracite blue	1977 - 1979
Yamaha	A-550	amplifier 40W	silver	1979 - 1981
Yamaha	T-760	tuner	silver	1980 - 1982
Yamaha	K-560	Cassette deck	silver	1980 - 1981
Yamaha	AX-470	amplifier 65W	Titanium	1993 - 1995
Yamaha	CDX-470	CD player	Titanium	1993 - 1995
Yamaha	KX-W282	Double deck	Titanium	1994 - 1995
Yamaha	TX-350	tuner	Titanium	1991 - 1995
complete stereo towers/sets in cabinet				
Beocenter	7002	combi 40W	rosewood/silver	1981 - 1983
Beovox	P45	speakers 45W	rosewood/black	1975 - 1980
Bang & Olufsen	Syst. Cabinet SC70	audiokast	rosewood/metal	1978 - 1982

Luxman	PD272	Turntable	woodcase/silver	1977 - 1982
Luxman	L-4	Amplifier 55W	silver	1979 - 1981
Luxman	T-2	tuner	silver	1979 - 1981
Luxman	K-12	cassette deck	silver	1979 - 1982
Luxman		original cabinet	woodcase/black	1979
Philips	305	MFB amp. 52W	silver	1980 - 1982
Philips	103	tuner	silver	

Philips	N5421	cassette deck FL	silver	
Philips		original cabinet	silver/black	
Philips	302L	MFB amp.. 45W	silver	1981
Philips	102L	tuner	silver	1981
Philips	N5151 Mk II	cassette deck FL	silver	1980 - 1981
Philips	F7211	turntable	silver	1981
Philips		original cabinet	dark wood	
Studio-gear				
Alecto	Pro-57	mixer&equalizer		2003
Monacor	SAM-500	mixer		1990
Numark (Dual)	CDN22 Mk4	Double CD Player	black	2008?
Numark		amp?	black	
Zoomstudio	1201	reverb&multi-effect	black	1997 - 2000
Alecto	MX-790	mixer	black	80-s?
D&R Aurex	DR	FX processor	black	1982
DBX II	model 128	noise reduction	black/alu	
DBX 21		Disk/Tape decoder	wood/black/alu	1981
Sanyo	Plus N55	noise reduction	silver	1980
Teac	AN-300	noise reduction	silver	1973
Reel to Reel				
Akai	GXM-11D	taperecorder	woodcase/silver	1972 - 1974
Mondo	MH-4A	taperecorder	beige/grey	70's
Philips	N4416	taperecorder	woodcase/silver	1972 - 1975
Sony	TC-200	taperecorder	black/lether	1964 - 1968
Sony	TC252	taperecorder	black/lether	1968 - 1972
Sony-O-Matic	TC-900	taperecorder	black/aluminium	1965 - 1969
Telefunken	Magnetophon105	taperecorder	silver/brown	1964 - 1966
Teleton	T-730	taperecorder	black/grey	60's
Uher	4000 report L	taperecorder	silver/steel	1966 - 1972
Uher	4400 Report	taperecorder	silver/steel	1972 - 1976
Vintage				
Dual	P-42	grammaphone	black/aluminium	1969
Grundig	RF720	kitchenradio	white/silver/black	1979 - 1980
Grundig		kitchenradio	woodcase/black	1979 - 1980
Lenco	B-51	grammaphone	grey	1960
Nokia	Viola 350	kitchenradio	woodcase/antrac.	1985 - 1987
Philips B5X04A Bi-A	stereo	kitchenradio	Brown	1960
Philips B5X04A Bi-A	stereo	kitchenradio	Brown	1960
Philips Buizenradio	stereo		woodcase	
Philips		pick-up	beige/bordeaux	

Philips	423	grammaphone	Orange	1973
Videorecorders				
Saba	VR-6008	Video recorder	black/brown	begin '80's
DVD Players				
Tegitel	DVD-100	DVD player	antracite	
Philips	DVDR 5520H	DVD Recorder HDD	black	
DVD/Video combi's				
Daewoo	SF-9300	DVD-Video player	silver	2010?
Daewoo	DF-8150	DVDrecorder/video	silver/chrome	2005?
Microphones				
Philips	N8216	microphone	black/silver	1980 - 1982
Headphones				
Pioneer	JB-100	electrostats	black/silver	1972
Cabels				
Cassettetapes NOS				
Videotapes NOS				
Gear				
Black = in stock, unchecked and uncleaned				
Blue = in repair/parts ordered/in service				
Green = in the storage or in the shop Doogan Records				
Red = not repairable/for parts				