Merk	Type		Color	Year
Turntables				
Akai	AP-Q41	turntable	silver	1982 - 1984
Denon	DP-51F	turntable	woodcase	1982 - 1985
Dual	CS-505-2	turntable	black	1987 - 1989
Dual	CS 606	turntable	woodcase/black	1980 - 1981
ERA	666	turntable	woodcase/silver	1972
Philips	212	turntable	woodcase/silver	1974 - 1976
Philips	212	turntable	rosewood/silver	1974 - 1976
Philips	Mignon AG2100	turntable	creme/bordeaux	1956 - 1959
Sony	PS-LX311	turntable	silver	1980
Toshiba	SR-F530	turntable	silver	1979 - 1982
Technics	SL-Q210	turntable	silver	1985
Technics	SL-D202	turntable 6kg	silver	1981 - 1982
Technics	SL-1900	turntable	black	
Thorens	TD-166 MkII	turntable	black/silver	1976 - 1984
Thorens	TD-160 MkII	turntable	silver/silver	1985 - 1987

USB Turntables				
Lenco	L3866 USB	turntable	silver	2015?
Lenco	L3866 USB	turntable	silver	2015?

Tangential	turntables			
Bang&Olufsen	Beogram 4002	turntable	nutwoodcase/silver	1974 - 1978
Bang&Olufsen	Beogram 4002	turntable	pinewoodcase/silver	1974 - 1978
Mitsubishi	LT-100	turntable	black	
Revox	B-790	turntable	grey	1977 - 1982
Technics	SL-J2	turntable DD	antracite	1984 - 1988
Technics	SL-DL1	turntable	silver	1979

Cartridges / headshells				
Audio Technica	AT-66	needle++	black/gray	'70's
Bang&Olufsen	MMC 20S	needle spherisch	black	
Bang&Olufsen	MMC 20EN	needle ellipt.nude	silver/aluminium	
Bang&Olufsen	MMC4000	4-channel cartr.	silver/aluminium	1972 - 1978
Garrard	GC-8	No.H24	gold	
Nagaoka	JT-511	needle	red	
Ortofon	VMS3MKII	in headsh.	black	1980
Ortofon	VMS 20E-MKII	needle	black	1980
Ortofon	Pro	needle 4 stuks	black	nieuw 39,-
Philips	GP 212		black	
Philips	GP 315	needle	black	
Philips	412 Gold MkII	New needle	gold	1980
Philips	412 Gold	in headsh.	gold/black headsh.	1980
Philips	412 Gold		gold	1980
Philips	412 Gold		gold	1980
Philips	412 MKIII SE	New needle	silver/black headsh	1982 - 1985
Pickering	XV-15 625E	in headsh.	silver	
Shure	M44-7	cartridge	brown	
Sony	headshell	straight	black	
Stanton	500	needle OK	gold/white	
Stanton	681 EEE	in original box	gold	
Tonar	187 DS	Seeburg	grey	

Yamaha	MC-7	MC Element	brown	1980 - 1984
Yamaha	MC-11	MC Element	transparant	1983 - 1997

Phono amplifiers				
NAD	PP2	phono pre amp	black	2009 - 2022
Philips	PA915	phono pre amp	grey	
Pro-Ject	Phonobox MM	phono pre amp	black	2019 - now
Pro-Ject	Phonobox MM/MC	phono pre amp	black	2019 - now
Cambridge Audio	Azur 640P	phono pre amp	silver	2010

Turntable combi's				

Amplifiers	**Integrated**			
Akai	AM-U210	amplifier 30W	silver	1982 - 1983
Goodmans	Maxamp 30	amplifier 15W	woodcase/silver	1966 - 1970
Harman/Kardon	A-401	amplifier 20W	silver	1975 - 1978
Kenwood	KA-8100	amplifier 75W	silver	1979
Kenwood	KA-400	amplifier 45W	silver	1980 - 1982
Luxman	SQ-505X	amplifier 30W	woodcase/silver	1970 - 1973
Luxman	L-505V	amplifier 55W	woodcase/silver	1975 - ?
Luxman	A-384	tube-amp. 95W	black aluminium	1995 - 2000
Luxman	LV-100	amplifier 35W	black aluminium	1988 - 1991
Luxman	LV-103U	tube-amp. 50W	black	1984 - 1987
Luxman	LV-105U	amplifier 80W	black aluminium	1986 - 1993
Luxman	LV-113	amplifier 70W	black	1988 - 1992
Luxman	LV-113	amplifier 70W	black aluminium	1988 - 1992
Philips	591	Versterker 20W	woodcase/zilver	1968 - 1972
Pioneer	SA500A	amplifier 13W	woodcase/silver	1973 - 1975
Sansui	AU-2900	amplifier 17W	black	1976 - 1977
Sansui	AU-777	amplifier 25W	black/white	1969
Yamaha	AX390	amplifier 60W	black	1996 - 1997

Pre- / Power-Amplifiers				
Cambridge Audio	P500	PowerA. 65W	black	2002
Proton	1100	Pre Amplifier	bronze	end '80's
Yamaha	CX50	Pre Amplifier	black	1988 - 1990

Receivers				
Denon	AVR-1603	AV Receiver 80W	black	2002 - 2003
NAD	C715	Receiver-CD 25W	black	2007 - 2012
Nakamichi	SR-3E	Receiver 45W	black alu	1987 - 1990
Onkyo	TX-8222	receiver 55W	champagn	2006 - 2007
Philips	777	Rec. MFB 55W	black	1978
Wega	R3141	Receiver 70W	Slate	1976 - 1977

Tuners				
Luxman	T92L	Tuner	black	1987
Luxman	T-341L	Tuner	black	1992 - 1993
Sony	XDR-S40DBP	DAB portable	black	2020?
Yamaha	TX540	Tuner	black	1990 - 1991

CD Players				
Cambridge Audio	D500	CD player	black	2002
Denon	DCD-980	CD player	black	1992 - 1993
Kenwood	DP-47	CD player	black	1988 - 1989
Luxman	D-373	CD player	black	1993 - 1996
Luxman	D-375	CD player	black	1996 - 2000
Luxman	D-351	CD player	black	1991 - 1993
Luxman	D-103U	CD player	black	1987 - 1993
Marantz	CD-273	CD player	black	1986 - 1987
Marantz	CD5000	CD player	black	2000
Meridian	588	CD player	black	
Nakamichi	OMS-2	CD player	black alu	1987
Nakamichi	CD-4	CD player	black alu	1992 - 1994
Onkyo	DX-7211	CD player	black	1996 - 1999
Pioneer	PD-4050	CD player	black	
Pioneer	PD-4700	CD player	black	1992
Pioneer	PD-107	CD player	black	1997 - 2000
Pioneer	PD-107	CD player	black	1997 - 2000
Philips	AK 601	CD player	antracite	1988 - 1992
Philips	CD100	CD player TL	silver	1982
Philips	CD100	CD player TL	silver	1982
Philips	CD200	CD player TL	silver	1983
Philips	CD300	CD player	silver	1983
Philips	CD210	CD player	antracite	1987 - 1990
Philips	CD604	CD player	black	1990 - 1992
Philips	CD604	CD player	black	1990 - 1992
Philips	CD732	CD player	black	1993 - 1994
Philips	CD782	CD player	black	1988
Teac	PD-H300	CD player	champagne/zilver	1997 - 2003
Mini Disc				
Sony	MDS-JE520	Mini Disc Rec.	black	1998 - 2007
Sony	MDS-JE520	Mini Disc Rec.	black	1998 - 2007
Walkmans				
Panasonic	RX-SA64	walkman/radio	black	1989 - 1990
Philips	EXP311	Discman	red	
Cassette Decks				
Akai	HX-27W	Double deck	black	1991 - 1996
Luxman	K-10	cassette deck	silver	1979 - 1982
Luxman	K-322	cassette deck	black	1995 - 2000
Nakamichi	DR-3	cassette deck FL	black alu	1992 - 1994
Nakamichi	480	cassette deck	silver	1979 - 1982
Nakamichi	480	cassette deck	silver	1979 - 1982
Nakamichi	480	cassette deck	black aluminium	1979 - 1982
Nakamichi	480	cassette deck	silver	1979 - 1982
Nakamichi	580	cassette deck	black aluminium	1979 - 1982
Nakamichi	550 portable	Cass. deck TL	black	1977 - 1979
Onkyo	TA-201	cassette deck	champagn	1991 - 1995
Philips	N2521	Cass. deck TL	silver/black	1977
Teac	R-H300	cassette deck FL	champagn.silver	1997 - 2003
Technics	RS-TR256	Double deck FL	black aluminium	
Yamaha	KX-580	cassette deck FL	black	1994 - 1997

Speakers Passive				

Akai	Jet Stream System	SW-35 15W	woodcase/metal	1971 - 1973
Aristona	SA 5417	speakers 10 W	woodcase-black	1975
Aristona	SA 5417	speakers 10W	woodcase-black	1975
Bang&Olufsen	Beovox S35	speakers 35W	rosewood/black	1977 - 1980
BNS	Jubilee	speakers 90W	woodcase-black	1986 - ?
BNS	Bronx 2	speakers 125W	black	1994
Blaupunkt	type 7621940	speakers	woodlook	70-s
Bruns Irel	HiFi Box FB 1H	speakers 25W	woodcase	begin 70?
B&W	DM-110i	speakers 75W	woodcase/grey	1986 - 1988
Dux (Philips S)	DX302	speakers 40/60W	woodcase/silver	4Ohm 16kg
Elac	EL 170S	floorspeakers 140W	black	1996 - 1999
Goodmans	Havant SL	speakers 20W	woodcase	1973 - 1977
Grundig	Box-300	speakers 20W	woodcase	begin 70?
Hitachi	LSG-235	speakers 20W	black/silver	1977
ITT	HiFi 8091	speakers 30W	woodcase black	1978 - 1979
JBL	TLX 8	speakers 150W	black	1984 - 1987
Jamo	150	Speakers 100W	Woodcase	1983 - 1984
JVC		speakers 20W	black	
JVC	SP-UXSG7VB	speakers 20W	black	2010 - 2015
JVC	Nivico MSB-501E	speakers 17W	woodcase	1970
Kenwood	LS-K701	Speakers 80W	woodcase light	2007
Linwood	SP-925	speakers	woodplastic	80-s
Mission	735	floorspeakers	black	1996 - 2004
Mission	M73i	floorspeakers	woodcase/pine	
Onbekend merk	kleine speakers	klein	woodcase	begin 70?
Onbekend merk	kleine speakers	klein	woodcase/silver	begin 80?
Peerless		Speakers ??W	Woodcase	1971
Philips	SX6456	Speakers 50W	black	4Ohm
Philips	22RH442	Speakers 10W	black	
Philips	22AH492	Speakers 20W	black	4Ohm
Pioneer	CS-313	speakers 20W	woodcase 8 Ohm	1974 - 1976
Telefunken	HiFi-Box TL500	speakers 50W	woodcase/metaal	1973 - 1975
Translator	Impact 5 Mk II	On foot	woodcase pine	1983 -1989
Sansui	S-33	speakers 40W	woodcase/black	1980
Sony	SS-A505	speakers 100W	black woodcase	1991
Sony	SS-CGPZ7	speakers 40W	woodcase/grey	2000?
Studio de Schop	Studio of Jumbo?	floorspeakers	white gloss	1985?
Tannoy	T125	Speakers 50W	woodcase/black	1979
Tannoy	Mercury Mk II	Speakers 120W	black	1986 - 1989
Tannoy	System 2	monitors	grey/antracite	
Wega	L4520	Speakers 90W	grey/antracite	1976 - 1979

Speakers Active				
Philips	MFB541	speakers	black	1976 - 1978
Philips	MFB544	speakers	black	1977 - 1979

Set in components				
Cambridge Audio	Azur 340A SE	amplifier 45W	silver	2009
Cambridge Audio	Azur340C	CD player	silver	2004 - 2009
Eurofunk	EFA-4000	amplifier	black aluminium	1981
Eurofunk	EFT-4000	Tuner	black aluminium	

Fisher-Barco	MT-6310	turntable	silver	1979
Fisher-Barco	GA-440	amplifier	silver	
Fisher-Barco	FM-440	Tuner	silver	
Fisher-Barco	CR-125	cassette deck	silver	
Grundig Japan	V5500	amplifier 70W	black aluminium	1992
Grundig Japan	CD5500	CD player	black aluminium	
Grundig Japan	T5500	Tuner	black aluminium	
Korn & Macway	KM52	active speakers	woodcase/black	1980
Korn & Macway	SP100	active processor	silver	1980
Korn & Macway	KM50	active speakers	woodcase/brown	1979
Korn & Macway	PR5	passive processor	silver	1979
LEAK	2000	Receiver 30W	woodcase/silver	1972 - 1975
LEAK	Sandwich 250	speakers 18W	woodcase	1974
Luxman	1000-K	cassette deck	silver	1996
Luxman	1000-D	CD player	silver	1996
Luxman	1000-PV	pre amp./tuner	silver	1996
Luxman	1000-MV	power amp. 50W	silver	1996
Luxman	L-30	amplifier 32W	woodcase/silver	1976 - 1977
Luxman	T-33	Tuner	woodcase/silver	1977 - 1978
Luxman	L-30	amplifier 32W	woodcase/silver	1976 - 1977
Luxman	T-33	Tuner	woodcase/silver	1977 - 1978
Luxman	L-200	amplifier 40W	silver	1982 - 1985
Luxman	T-240	Tuner	silver	1984 - 1987
Luxman	K-210	cassette deck FL	silver	1983 - 1985
Luxman	LV-113	amplifier 70W	black	1988 - 1991
Luxman	T-111	Tuner	black	1987 - 1993
Luxman	D-113D	CD transport	black	1988 - 1990
Nakamichi	Soundspace 5	wallset+speakers	silver	2000
3 sets samen te stellen:				
Nakamichi	Receiver 3	receiver 37W	antracite alu.	1991 - 1994
Nakamichi	Receiver 3	receiver 37W	antracite alu.	1991 - 1994
Nakamichi	Amplifier 2	amplifier 50W	antracite alu.	1991 - 1994
Nakamichi	CD Player 3	6 CD changer	antracite alu.	1991 - 1994
Nakamichi	CD Player 4	CD player	antracite alu.	1991 - 1994
Nakamichi	Tuner 2	Tuner	antracite alu.	1991 - 1994
Nakamichi	cassettedeck 2	cassette deck	antracite alu.	1991 - 1994
Nakamichi	cassettedeck 2	cassette deck	antracite alu.	1991 - 1994

Philips	202	turntable	woodcase/silver	1969 - 1972
Philips	591	amplifier 20W	woodcase/silver	1969 - 1972
Philips	691	Tuner	woodcase/silver	1969 - 1972
Philips	N2506	cassette deck TL	woodcase/silver	1972 - 1974
Philips	22RH433	Speakers 20W	woodcase	4Ohm 1975
Philips	N8402	microphone	silver	1973 - 1975
Philips	Power Amp. 309	microset 55W	silver	1980
Philips	Pre Amplifier 209		silver	1980
Philips	Quartz tuner 109		silver	1980
Technics	SE-HD501	amplifier 24W	silver/woodsides	1998 - 2001
Technics	SL-HD501	CD player		
Technics	RS-HD501	cassette deck		
Technics	ST-HD501	Tuner		
Technics	SB-HD505	speakers 30W	pine/grey	1998 - 2001
Technics	SL-CH530	CD player	black	1995 - 1996
Technics	RS-CH730	Double deck	black	
Technics	ST-CH530	Pre amp./tuner	black	
Technics	SE-CH530	Power amp. 35W	black	
Technics	SB-CH530A	speakers 35W	black	
Servosound	Cybernetic SL20	4 active speakers	woodcase/silver	1970
Servosound	Cybernetic SP70	Pre Amplifier	woodcase/silver	1970
Yamaha	MCR-940	Pianocr. BlueRay!	silver + remote	2011 - 2015
Yamaha	MCR-840	Pianocraft CD 65W	silver + nw. remote	2011 - 2015

complete stereo towers/sets in cabinet				

Studio-gear				
DAP Audio	K-112	4 speakers	black	2011?
JBSystems	Beat6 Mk2	Mixer	silver	2004?
Ohio Sound	ULX280	studioamplifier	black	
Sansui	Audio Mixer AX-7	Pre Amplifier	black	1977 - 1980
Sky Tronic	PA2200	studioamplifier	black	
Skytec/Vonyx	SL??	speakers passive	black	
Stanford	M1773	Stereo mixer	black	1978
Ecler	MAC 55	mixer	antracite	
Vonyx	STM-2290	mixer (small)	black	2023 - now

Reel to Reel				
Sony	TC-366	taperecorder	woodcase/silver	1972 - 1975
Multitrack		8-track player	woodcase/silver	

DVD Players				
Cambridge Audio	DVD89	DVD player	silver	
Denon	DVD1400	DVD player	black	2003 - 2005
Denon	DVD1710	DVD player	black	2004
JBL	DSC 500	DVD 5.1 surround	silver	2000
LG	DVX692H	DVD player	black	
Samsung	BD-J4500	Blu Ray player	black	
Sony	RDR-HX725	DVD recorder	black	
Sony	DVP-NS355	DVD player	black	2004 - 2005

DVD/Video combi's				

Vintage				

Videorecorders				
Sony	SLV-E270	Video recorder	black	1996

Microphones				
Akai	ADM-25	microphone	silver	1982
Philips	EL1979	microphone	silver	1967 - 1968
Beyerdynamic	M69TG	microphone	black	2001 - 2011
Technics	RP-3330	microphone	silver	1979 - 1981
Rossetti	model 9000	microphone	black	1980?
Sony	F-96	microphone	grey/silver	1966 - 1970
Geloso	M 68	micr. 250 Ohm	silver	1967

Headphones				
Sansui	SS-10	headphone	white/black lether	1973 - 1976
Nakamichi	HF-100	headphone	black	1975 - 1976
Divine	Pro 5000	headphone	black/lether	
Micro Seiki (Stax)	MX-5	electrostat	silver/black	1977 - 1980

Cabels				
QED	SQART Silver	high end scart	gold/blue	
Oehlbach	the pure sound	scart cable	black/yellow	
Monacor	CCX-6M	headphone cable	black	

Cassettetapes NOS				
TDK	D-60	60min (normal) I	sealed	
Maxell	UR-90	90min (normal) I	sealed	
Maxell	SQ-90	90min (chrome) II	sealed	
Hema		90min (normal) I	sealed	
Sony	C-90 HFC	90min (normal) I	sealed	

Videotapes NOS				

Maxell	M180	180min		
Sony	240DX	240min		
TDK	HS180	180min		

Gear				
National	BH-653E	antistator		
Tonar	manual	discwasher		
Philips	cleaning set	video, tape, CD		